

# INT-AC-C411



uReader-A PWR-Carrier

## 1. Descripción - Description:

Descripción técnica del cable INT-AC-C411 para conexión del producto uReaderGPS a través del conector A. Permite alimentación del equipo y conexión serie RS232 para maquinas de frío Carrier para la obtención de temperaturas y datos de diagnóstico.

Technical description of cable INT-AC-C411 for uReaderGPS through the A connector. Allows power supply and RS232 serial connection to Carrier Reefers to read temperature and diagnostic data.

## 2. Esquema - Schematics:



! El color de los cables se utiliza sólo como referencia. El color puede cambiar sin previo aviso. Compruebe siempre que cada cable llega al pin del conector correspondiente.

! The wire colors are only as reference. The color may change without notice. Always check that each wire reaches the correct pin of the connector.

## 3. Compatibilidad – Compatibility

- uReaderGPS
- Carrier Ultra
- Carrier Vector

## Document revision History

| #   | Date       | Author | Apvd  | Changes                                  |
|-----|------------|--------|-------|--|
| r01 | 2014/05/14 | JVL    | JJBMT | First release                            |
| r02 | 2015/06/16 | JVL    | JJBMT | Added compatibilities                    |
| r03 | 2016/02/12 | JVL    | MLG   | Updated image                            |
| r04 | 2017/04/24 | FGM    | MLG   | Logo/Header contact details updated.     |
| r05 | 2017/06/06 | FGM    | FGM   | Image updated.                           |
| r06 | 2017/09/18 | FGM    | JVL   | Schematics Added.                        |
| r07 | 2020/10/15 | FGM    | FGM   | Adapt CI + source format export to Gdoc. |