

INT-AC-C414


uReader-B PWR+RemoteStart-ThermoKing SR2,3&4

1. Descripción - Description:

El cable INT-AC-C414 permite la conexión de uReaderGPS con las máquinas de frío Thermo King SR2, SR3 y SR4. La comunicación se realiza mediante CANbus. El cable permite alimentar el equipo uReaderGPS, leer y modificar todos los parámetros de la máquina de frío, realizar diagnóstico remoto de errores y controlar remotamente el encendido y apagado.

The INT-AC-C414 cable allows the connection between uReaderGPS and Thermo King SR2, SR3 & SR4 reefers. Communication is done through CANbus. It allows to power uReaderGPS, read and modify all the parameters of the reefer, perform remote diagnosis of errors and remote start & stop.

2. Esquema - Schematics:



! El color de los cables se utiliza sólo como referencia. El color puede cambiar sin previo aviso. Compruebe siempre que cada cable llega al pin del conector correspondiente.

! The wire colors are only as reference. The color may change without notice. Always check that each wire reaches the correct pin of the connector.

3. Compatibilidad – Compatibility

- uReaderGPS
- Thermo King Smart Reefer 2
- Thermo King Smart Reefer 3
- Thermo King Smart Reefer 4

Document revision History

#	Date	Author	Apvd	Changes
r01	2018/08/02	JVL	MLG	First release
r02	2020/10/15	FGM	FGM	Adapt CI + source format export to Gdoc.